

## Whole house extract units-Self-regulating ventilation groups

### OZEO E ECOWATT 2 Series

#### OZEO E ECOWATT 2

Whole house extract units that ensure permanent renewal of air in single dwelling houses or multi-dwelling blocks (individually). The unit is complemented with self-adjusting extraction BAR valves, (installed in kitchen, toilets, bathrooms) and self-regulated air inlets located in the main rooms (dining rooms, bedrooms).

This range has available a CO2 model that adjusts the airflow according to the CO2 concentration detected by the sensor.

The OZEO-E ECOWATT DHU model regulates its proportional or minimum-maximum flow rate depending on humidity.

#### Versions

OZEO-E ECOWATT 2 with wiring remote control. (Not included)

OZEO-E ECOWATT 2 RF with radiofrequency remote control. (Included)

OZEO-E ECOWATT CONTROL CO2 with radiofrequency remote control and CO2 sensor. (Included)

OZEO-E ECOWATT DHU with remote control with cable and humidity probe (included).

#### Configuration

- Three-speed motor (two of them are adjustable). Except DHU version with 2 adjustable speeds
- 4 Ø125 mm extract air spigots, to use in bathrooms and kitchens. Include gasket and pivoting 90° possibility.
- 1 Ø125 mm outlet spigot pivoting 360°.
- 3 caps to seal unused spigots.
- 1 template to facilitate fitting on the ceiling or wall.
- Wireless proportional CO2 sensor for OZEO-E ECOWATT CONTROL CO2 model.
- Wireless remote control with 3 speeds for OZEO-E ECOWATT 2 RF model.
- Proportional humidity probe incorporated into the equipment and remote control with cable for the model OZEO-E ECOWATT DHU.



## Attributes



#### CONTROL REMOTO OZEO-E ECOWATT 2 RF

Wireless 3-speed remote control within the scope of supply of OZEO-E ECOWATT 2 RF



#### CONTROL REMOTO OZEO-E ECOWATT CONTROL CO2

Wireless 3-speed remote control within the scope of supply of OZEO-E ECOWATT CO2

#### SONDA CO2

Wireless remote control, with 3-speed or proportional by CO2 sensor, within the scope of supply of OZEO-E ECOWATT CO2

---

#### **PULSADOR OZEO E ECOWATT DHU**

Cable control, for activation of peak flow timed and alerts failure, included with the model OZEO E ECOWATT DHU